


Sectional Drawing



Part Number	Description	Part Number	Description	Part Number	Description
101	Suction/Discharge casing	➤ 433.2	Mechanical Seal	903	Plug
➤ 137	Suction & discharge plate	507	Thrower	903.1	Plug
180.5	Valve Plate	554.L	Anti-unscrewing washer	906	Tie bolt
183	Support foot	554.5	Spring washer	914	Screw
➤ 210	Shaft	554.6	Washer	914.1	Screw
➤ 230	Impeller	562	Cylinder Pin	920	Nut
235	Impeller cover	685	Mesh guard	932	Circlip
➤ 320	Ball bearing	801	Flanged motor	935	Wafer ring
330	Bearing housing	861.1	Half coupling	940	Key
341	Motor lantern	861.2	Half coupling	940.1	Key
360.1	Bearing cover	➤ 861.3	Coupling insert	Z	Liquid Supply Inlet
➤ 400.9	Gasket	901.1	Screw		
➤ 411	V-ring	901.2	Screw		

➤ = Recommended spare parts



Premier Fluid Systems
Canadian Home of Travaini Pumps

4161 Morris Drive Burlington Ontario L7L 5L5
Tel: 1-800-461-2611 or 905-637-2611 Fax: 905-333-4722
E-mail: info@pfspumps.com Website: www.pfspumps.com

DATE : OCT 2011

N°.: 6.18.3